
## Keep Carrier Bolts on the Mark



Dear Editor,


Crewmen are supposed to keep a sharp eye out for loose sprocket carrier bolts on all M2/M3-series Bradleys.

But unless the bolts have loosened enough to move with your fingers, it's hard to tell a tight bolt from one that's just started coming loose.

A simple grease pencil mark solves this problem. After the bolts are torqued in place, we use the grease pencil to draw a line over each bolt head, forming a circle all the way around the face of the sprocket carrier.

If one of the bolts comes loose, the line on the bolt head moves and is easy to spot.

> SFC Duaine Buck 3/3d ACR Ft Carson, CO



FROM THE DESK OF THE Editor We give you high marks for that idea!